MICRAFT




Advance and Profession series User Manual May 2019 v1


Printing work flow

This manual focus on the work flow of Printer hardware operation and after printing process.


MICRAFT



1. Get 3D file (*.stl) from a. CAD b. 3D scanner



- 2. 3D file preparation
 - a. Repair 3D file
 - b. Build supports
 - C. Slice (Layer thickness)



- 3. Printing setting
 - a. Material selection
 - b. Tilt speed
 - c. Printing optimization



- 4. Printer operation
- 5. After printing a. Post curing

 - b. Remove supports
 - c. Grinding (optional)

Strictly Confidential

Main Content


MICRAFT

- 1. Printer and Accessory
- 2. <u>Safety Precautions</u>
- 3. <u>Specification</u>
- 4. Power on and off
- 5. Remove and install build platform
- 6. Fill resin
- 7. Change Tank
- 8. Clean Teflon Module
- 9. Maintenance- Change Teflon film

10. After printing

Printer and Accessory

Check out all the elements in your printer package.



MICRAFT

Printer and Accessory

MIICRAFT

Check out all the elements in your printer package.



Accessory box (1)Adapter 1 unit (2)Cord 1 unit (3)Putty knife 1 unit (4)M3 Wrench 1 unit (5)Plastic plate 1 unit (6)Stopper 4 units (7)RJ-45 cable



Safety Precautions

- Please read through the following Safety Precautions before you start using your printer.
- (1) Warning : "Build platform" and "Tank" is hazardous moving parts in MiiCraft Printer. Keep body parts out of picker's motion path.
- (2) Emergency shut down method : Press the power button to shut down. Or unplug the power cord.
- (3) Use only the power adapter provided by the supplier.
- (4) Before plugging the power adapter and cord into an electrical outlet, verify the local power rating conforms with the specified voltage and frequency.
- (5) This printer needs a grounded, 1-phase electrical power source.
- (6) Make sure power and communication cables are well managed to prevent from tripping.
- (7) Do not disassemble or repair the device yourself. Doing so may cause device malfunction or danger.

Safety Precautions

MICRAFT



- (8) Chemical substances like resin may cause skin irritation, please read the guidelines in Material Safety Data Sheet (MSDS) of the resin supplied by manufacturer. It is recommended to wear gloves when doing the printing process.
- (9) Keep door closed during printing or curing to prevent UV leakage.
- (10) UV light may cause injury of eyes, do not stare into the printer directly when it is in operation. It is recommended to wear UV protective glasses during operating the printer.
- (11) Place the device on a level surface and keep the printer in an upright position at all times, especially in transportation.
- (12) Do not store the printer in extreme hot and cold temperatures.
- (13) Do not expose the resin tank to direct light source because the resin will solidify under UV light.
 When moving the printer, be sure to take our tank or make sure there's no resin inside the take to prevent resin leakage.

Product Name	Advance 255/205 Profession 250/120			
Power Input	With Adapter : 100~240V AC, 2A, 50/60Hz			
Net Weight	310 kg			
Package Size and	L*W*H 117*107*225 cm / 428 kg (Including pallet)			
Weight	(Package design and size is possibly change)			
Operating Temperature	10° to 30°			
Humidity (RH)	40% to 60%			
	Our printer should keep in dry conditions			
Storage of Printing	Store the materials at ambient temperature from 15° to			
Material	28 °			
	And do not exposure to the light, otherwise resin may			
	solidified			
Liability: In case you do not follow the operating manual we cannot be held				
responsible for damages of the machine or injuries on the operator.				

MICRAFT

	Advance 255	Advance 205	Profession 250	Profession 120	
Building size (mm)	255x235x190	205x185x190	250x140x190	120x67x190	
XY Resolution	125um	100um	65um	30um	
Туре	Dual 1080P	Dual 1080P	4K Ultra HD	4K Ultra HD	
Wavelength (LED)	405nm	405nm	405nm/385nm/3 65nm	405nm/385nm/3 65nm	
I/O	Ethernet / USB / Wifi / Power in, Adapter: 100~240V AC, 2A, 50Hz/60Hz				
Size and Weight	819(W)x750(D)x2000(H) mm / 300kg				

Power on and off

MICRAFT



Power Button


Power On Press Power Button => Panel shows Starting up => Panel shows Menu

Power Off Press Power Button => Confirm message => Confirm to shut down

Remove and Install Build Platform

MICRAFT






(1) Loosen 2 screwsTurn the screws counterclockwise

(2) Holding two handles beside the build platform, and slowly pull out the build platform

(3) Be careful to holding the build platform, especially the moment detach from the track

Remove and Install Build Platform









(1) Put the build platform back, push to the end(2) Turn the 2 screws clockwise until tight ---finish

Fill Resin

MICRAFT






There are lines scale

- (1) Fill resin
- (2) Suggest filling height:

Between red line as picture on the corner of tank (4 place) right, in the case tank is inside the printer.

If the tank is out of the printer, suggest the resin level slightly lower than red lines.




In the case tank is inside the printer



Change Tank How to take out and install tank module?

MICRAFT







(1) Loosen 4 screws Turn the screws counterclockwise

Change Tank How to take out and install tank module?

MICRAFT




(2) Pull out two side stoppers(Right and Left side of tank)



Change Tank How to take out and install tank module?

MIICRAFT



(3) Pull out the tank module--Finish



Install the tank module :

(1)Put the tank module back(2)Return two side stoppers(3)Turn the 4 screws clockwise until tight--Finish


Clean Teflon module How to separate Teflon module from Tank module?

MIICRAFT



Clean Teflon module How to separate Teflon module from Tank module?

MIICRAFT



(1) Use M3 wrench to loosen 6 screws on the outside



Inside screws : no need to loosen

Outside screws : need to loosen



Clean Teflon module

MICRAFT

- (1) Pour Resin out of teflon module
- (2) Use ethanol to clean the tank
- (3) If needed, you can use tissue to clean teflon



MICRAFT

When printing failure happen, there may have some printing residual left and stick on teflon module.

Before to start another printing job, be sure to clean the printed residual out of teflon module.

- (1) Use "Clean tank" function via touch panel, it project a complete patter, the residual will be transformed into a solid layer.
- (2) Using the scrape, scoop up one side of the layer. Then carefully lift to remove solid layer from the teflon module.



Maintenance How to replace teflon film on a teflon module?


MICRAFT

Teflon film is consumable, we recommend to replace teflon film when it has been using for a period, and user discover the printing quality getting worse.




Maintenance How to replace teflon film on a teflon module?

MIICRAFT



(1) Use M3 wrench to loose all screws on the Back of teflon module





(2) Remove the <u>screws</u> and <u>Rubber</u> and teflon film


Strictly Confidential


Maintenance How to replace teflon film on a teflon module?

MICRAFT



(3) Put the new rubber onto the gap Make sure the rubber fit into the gap






(4) Put the teflon film module, and fit with two position pin. Only one side can fit with position pin


(5) Use M4 wrench to fix all screws on the back of teflon module ----Finish.

MICRAFT



(1) Use polypropylene (PP) scraper to wipe the excess resin on top of the build platform

(2) Take out the Build platform



(3) Use air gun to clean the printed parts

MICRAFT



(4) Use utility knife to separate the base



(5) Use putty knife or plastic scraper remove the printed parts from build platform

MICRAFT



(6) Use ethanol to clean the printed parts

(7) Use water to clean the printed parts or use ultrasonic cleaning machine.

(8) Clean until the water become clear





MICRAFT





(9) Use air gun to let printed parts dry

(10) Use Curing box to cure the printed parts until it totally dry---finish





Thank you